## Converting From Gaia Magnitudes to LSST Photon Counts

David Thomas

May 7, 2020

## Gaia mags to SDSS mags

We start with Gaia bands  $G, G_{BP}, G_{RP}$  from the Gaia DR2 catalog. Then we use the regression from GAIA Data Release Documentation Section 5.7 to map these to the r-band SDSS magnitude  $m_{SDSS}$ :

$$m_{SDSS} = G + 0.12879 - 0.24662 \cdot (G_{BP} - G_{RP})$$
$$+ 0.027464 \cdot (G_{BP} - G_{RP})^2 + 0.049465 \cdot (G_{BP} - G_{RP})^3$$

## SDSS mags to LSST photon counts

SDSS mags differ from an AB system at the few percent level in the r-band (SDSS Flux Calibration). In this analysis we treat it as a perfect AB system. SDSS lists magnitudes in Asinh, which asymptotically approach the classical magnitude relations for bright sources (SDSS Measures of Flux and Magnitude). In fact, for r-band magnitudes below 22.29, the asinh magnitude and traditional logarithmic magnitude differ by less than 1%. Since most of the sources we will use for donuts are well within this range, we employ the traditional formula in this analysis.

We start with the AB mangitude relation

$$m_{SDSS} = -2.5 \log_{10} \left( \frac{\int f(\nu) (h\nu)^{-1} S_{SDSS}(\nu) d\nu}{\int (3631 \ Jy) (h\nu)^{-1} S_{SDSS}(\nu) d\nu} \right)$$

where  $S_{SDSS}(\nu)$  is the total (atmosphere + filter + detector) transmission curve for SDSS in the r-band. The zero-point magnitude is defined  $m_z = 2.5 \log_{10}(\int (3631 \ Jy)(h\nu)^{-1} S_{SDSS}(\nu) d\nu)$ . The value for the SDSS r-band is  $m_z = 24.80$ . We also make the assumption that  $f(\nu) = \alpha B(\nu, T)$  where B is the spectral irradiance of a blackbody and  $\alpha$  is constant. Then we have,

$$10^{(m_z-m_{SDSS})/2.5} = \alpha \int B(\nu,T) S_{SDSS}(\nu) (h\nu)^{-1} d\nu = \alpha h^{-1} \int B(\lambda,T) S_{SDSS}(\lambda) \lambda^{-1} d\lambda$$

We can solve for the constant f

$$\alpha = \frac{h \cdot 10^{(m_z - m_{SDSS})/2.5}}{\int B(\lambda, T) S_{SDSS}(\lambda) \lambda^{-1} d\lambda}$$

Now that we have the flux multiplier  $\alpha$ , we can compute the LSST photon count by taking a similar integral over the bandpass and multiplying by the exposure time  $t_{exp}$  and primary mirror area  $A_{LSST}$  as follows

$$n_{LSST} = \alpha \cdot A_{LSST} \cdot t_{exp} \cdot h^{-1} \int B(\lambda, T) S_{LSST}(\lambda) \lambda^{-1} d\lambda$$
$$= A_{LSST} \cdot t_{exp} \cdot 10^{(m_z - m_{SDSS})/2.5} \cdot \frac{\int B(\lambda, T) S_{LSST}(\lambda) \lambda^{-1} d\lambda}{\int B(\lambda, T) S_{SDSS}(\lambda) \lambda^{-1} d\lambda}$$

We precompute the ratio  $\frac{\int S_{LSST}(\lambda)\lambda^{-1}d\lambda}{\int S_{SDSS}(\lambda)\lambda^{-1}d\lambda}$  for a range of temperature values to speed up the computation in 'transmission.py'. We interpolate between these cached values.